


FLATIRON STEEL 7/8" CORRUGATED

7/8" CORRUGATED INSTALLATION GUIDE



www.FLATIRONSTEEL.com

FLATIRON STEEL

7/8" CORRUGATED

Table of Contents

General Notes

Claims	1
Returns	1
Storage	1
Handling	1
Foot Traffic	1
Safety	2
Field Cutting Panels	2
Condition of Substrate and Structure	2
Tools & Equipment	3
Roof Maintenance	3
Warranty Information	3
Installation	4
Fastener and Selection Guide	5-6
Material Specifications	7

Flashing Details

Trim Profiles	8-11
Vented Ridge Cap	12
Non - Vented Ridge Cap	12
Hip / Ridge	13
Front Cap	13
Gable	14
Eave	14
Square Base	15
Endwall	15
Sidewall	16
Snow Stop	16
Inside Corner	17
Outside Corner	17
Window Drip Cap	18
Upper Transition	18
Lower Transition	19
W-Valley	19
Z-Base	20
Z-Flashing	20
Prow Gable	21
Overall Dormer	22
Ridge Tie-In	23
Valley-Tie-In	23

**Please contact us for more information.*

FLATIRON STEEL

7/8" CORRUGATED

INFORMATION

This guide has been provided as a reference and helpful tool for installing Flatiron Steel's 7/8" Corrugated Panel. The installation details shown may not apply to all building designs, codes, or product applications. It is the responsibility of the installer to ensure the details meet code in his/her area.

Flatiron Steel reserves the right to change any information in this guide, at any time, without notice. If you have any questions or concerns, please contact your Flatiron Steel representative.

CLAIMS

It is the responsibility of the customer to review the condition and quantities of an order upon pick up or delivery. Claims for any shortages or damages must be filed immediately for orders picked up, or within 48 hours for orders delivered. Flatiron Steel will not be held responsible for any claims filed after these time frames.

RETURNS

Flatiron Steel does not accept returns of any custom ordered materials, special ordered accessories, or fabricated metal products. Only stock accessories may be returned if they are deemed to be in resalable condition. Stock items being screws (full bag quantities), flashers, closures, clips, underlayment, etc. A restocking fee of 15% may be applied to all returned merchandise.

STORAGE

If the metal panels or trim are not used immediately, the metal should be stored in a well ventilated, cool, dry place. This will inhibit moisture build up on the panels and trim, which can lead to white rust.

If the product cannot be stored indoors, elevate one end of the bundle to allow any moisture to run off the panels. Also, a tarp should be loosely wrapped around the bundle, ensuring there is good air flow around the panels. Never store panels in direct contact with the ground.

Flatiron Steel assumes no responsibility for materials that are not stored properly.

HANDLING

Handle all panels and trim with care to avoid damage. When unbundling panels, do not drag one panel against another. This can cause scratches across the panels. When moving the panels, they should be carried vertically to the ground by grasping the edge of the panel carefully to ensure that no excessive bending occurs. Note, the edge of the panel is sharp, and gloves should always be worn when handling all metal.

When handling trim it is important to do so with care and ease. Many trim profiles are fragile and can be easily damaged if not handled appropriately. It is recommended that the installer or whomever is handling trim wear gloves and use two hands at all times.

FOOT TRAFFIC

Care of metal panels and trim must be exercised throughout installation. Foot Traffic can cause distortion of the panel and damage the finish. Foot traffic should be kept to an absolute minimum. Installers should wear soft soled shoes that will help with traction on the roof and prevent scratching.

When walking on the panels is unavoidable, walk in the flats only. Walking on the major ribs can damage the panel.

FLATIRON STEEL

7/8" CORRUGATED

SAFETY

Safety should be the main concern when installing any metal project. Each job site presents different hazards, on the ground and the roof; therefore, it is the responsibility of the installer to determine the safest way to install the metal.

Personal protective equipment should be used at all times when handling or installing metal panels and trim (i.e. gloves, safety glasses, pants, long sleeved shirts and hard hats).

Always be aware of your surroundings and use fall protection. Never install metal roofing during windy or stormy days. Metal roofing can become slippery when wet or dusty and extra care needs to be taken if these conditions are present. Wind can create hazardous working situations by getting under the metal panel and pulling the installer off the roof. Metal roofing is very sharp and can cause serious bodily injury if handled inappropriately.

If a safety concern exists on a job site, stop work immediately. Always comply with OSHA safety regulations.

FIELD CUTTING PANELS


Tin Snips, a circular saw, or a nibbler is recommended for field cutting metal panels and trim. Always wear eye and ear protection when cutting metal. When cutting painted metal, ensure the metal particles and fragments do not end up on the painted surface. Metal particles on the painted surface will result in rusting and pitting in that area. Flatiron Steel recommends the panels to be turned upside down and all cutting be done looking at the backside of the material. Installers should immediately wipe away any debris from the material after cuts to prevent this problem. Panels should be cut in an area where metal particles do not end up on other panels or building materials.

****Failure to remove the metal particles from the panel will void any warranty****

CONDITION OF SUBSTRATE AND STRUCTURE


Before the installation process begins, it is critical that the framing and substrate are inspected to ensure that the structure is square and plumb. If it is not, it will have to be corrected. Make sure any structural fixes are done by someone with the proper experience and knowledge. Correct any objectionable warp, waves, or buckles in the substrate before proceeding with panel installation. The roof panels will follow the contour of the structure and may appear irregular if not corrected.

To check the structure for squareness, take two diagonal measurements from the corner to corner. The roof is square if the two measurements are equal.



If the roof is not square, follow the 3-4-5 method to ensure that the panel is being installed square. If the first panel is not installed square, all remaining panels will also be out of square when attached to the structure.

- 1.) To do this, pick a starting point at the bottom corner of the roof, about a foot away. Set a nail there.
- 2.) From the nail, measure exactly 3 feet in the opposite direction along the bottom edge of the roof. Insert another nail in that spot.
- 3.) From the first nail, measure exactly 4 feet up the slope of the roof and draw a small arc.
- 4.) Measure from the second nail up to the arc measuring exactly 5 feet, drawing another arc.
- 5.) Attach a chalk line to the first nail and extend it up the slope until it passes through the intersection of the two arcs.
- 6.) Snap the chalk line. This line is now square with the bottom edge of the roof.
- 7.) Use this line to properly install the first panel square on the roof.¹



¹For larger roofs, this method can be done with multiples of 3,4,5
Example 6', 8', 10'

FLATIRON STEEL

7/8" CORRUGATED

TOOLS & EQUIPMENT

- Hard Hat
- Gloves
- Safety Glasses
- Ear Plugs
- Fall Protection
- Screw Gun
- Tin Snips
- Tape Measure
- Chalk Line
- Electric Nibbler
- Circular Saw
- Angle Grinder
- Rivet Gun

ROOF MAINTENANCE

Roof maintenance should be done, at the minimum, annually. These steps will ensure that your roof will have a longer lifespan with less maintenance and help prevent costly repairs. It is best to perform roof maintenance when the weather permits safe working conditions.

- Clear all debris off the roof (dirt, rocks, branches, leaves, etc.)
- Clean out all drains and gutters to ensure proper drainage, to prevent water standing.
- Remove any overhanging branches or anything else that could penetrate the roof surface.
- Inspect all areas for leaks and deterioration - pay attention to stains and discoloration of the roof edges and surrounding walls as they are possible indications of a leak.
- Check roof penetrations for possible leaks and cracks in caulking.
- If exposed fasteners have been used to install the roof, it is crucial they are inspected annually.
 1. Check if they are installed correctly.
 2. Ensure that they are not fastened too tight or not tight enough.
 3. Inspect the integrity of the neoprene washer.

Refer to Fastener selection guide on the following pages 5-6.

PAINT WARRANTY

Warrant documents are available upon written request.

Please provide the following information to your local Flatiron Steel branch.

Product purchased - Including: panel type, width, color and gauge.

Where the product was purchased: Lumber yard, roofing wholesaler, contractor or direct.

When the product was purchased: Date of purchase (must be within 90 days of purchase date)

Owners Name:


Project Location: Physical address

Job Completion Date:

FLATiRON STEEL


FASTENER SELECTION GUIDE

WOODFAST SCREW




- No. 10 x 15, Type 17
- Available sizes: 1", 1 1/2", 2", 2 1/2", 3"
- 1/4" Hex Head
- Use: Panel to dimensional lumber and trim attachment.

WAFER SCREW




- No. 14 x 10, Type 17
- Available sizes: 1", 1 1/2", 2"
- 5/16" Hex Head
- Use: Panel to plywood/OSB substrate and trim attachment.

STITCH SCREW




- No. 12 x 14
- Available size: 3/4"
- 1/4" Hex Head
- Use: Trim attachment and stitching lap seams together (29 gauge).
- **Compatible with No. 10 & No. 14 Wood Screws*

TEK SCREW



- No. 12 x 14
- Available sizes: 1", 1 1/2", 2"
- 5/16" Hex Head
- Use : Panel to Purlin (up to 3/16" steel).

PROPER INSTALLATION OF GASKETED FASTENERS




- This table shows the fasteners available from FLATiRON Steel. Refer to the panel installation and flashing details of this manual for specific screw usage and spacing.
- Panel attachment screws must be long enough to fully penetrate through the wood roof decking, steel purlins or penetrate solid lumber at least one inch.
- All screws must be coated to provide protection against corrosion.
- Exposed fasteners must have sealing washers and should be the same color as the parts they attach.
- Screws must be properly driven to ensure proper seal and holding strength. Do not underdrive or overdrive the screws.
- Stainless steel rivets are not watertight.

FLATiRON STEEL

FASTENER SELECTION GUIDE


LAP TEK



- No. 14 x 7/8"
- Available size: 7/8"
- 5/16" Hex Head
- Use: Trim attachment and stitching lap Seams together .

**Compatible with No. 12 Tek Screw and No. 14 Wafer Screw*


TEK 5



- No. 14 x 24
- Available size: 1 1/4"
- 5/16" Hex Head
- Use: Panel to purlin (Heavy Gauge Steel 3/16" and greater).

**Only Available in white and galvanized, remaining colors available by special order.*

PANHEAD




- 10 x 12
- Available sizes: 1", (1 1/2" and 2" available by special order)
- Phillips Head / Square Drive
- Use: To fasten standing seam panels and trim to wood deck (unexposed).

STAINLESS STEEL RIVET POP RIVET



- Available sizes: 1/8" x 3/16"
- Use: Trim attachment

PROPER INSTALLATION OF GASKETED FASTENERS




- This table shows the fasteners available from FLATiRON Steel. Refer to the panel installation and flashing details of this manual for specific screw usage and spacing.
- Panel attachment screws must be long enough to fully penetrate through the wood roof decking, steel purlins or penetrate solid lumber at least one inch.
- All screws must be coated to provide protection against corrosion.
- Exposed fasteners must have sealing washers and should be the same color as the parts they attach.
- Screws must be properly driven to ensure proper seal and holding strength. Do not underdrive or overdrive the screws.
- Stainless steel rivets are not watertight.

FLATIRON STEEL

7/8" CORRUGATED

MATERIAL SPECIFICATIONS



LOAD TABLES

Refer to Trim Pamphlet for Material Availability

24 Gauge (0.0223"), Fy = 50 ksi, Fu = 60 ksi								
SPAN TYPE	LOAD TYPE	SPAN IN FEET						
1-span	NEGATIVE WIND LOAD	3.0	4.0	5.0	6.0	7.0	8.0	9.0
	LIVE LOAD/DEFLECTION	161.82	91.03	58.26	40.46	29.72	22.76	16.82
2-span	NEGATIVE WIND LOAD	105.98	44.71	22.89	13.25	8.34	5.59	3.93
	LIVE LOAD/DEFLECTION	159.03	90.13	57.89	40.28	29.63	22.70	17.95
3-span	NEGATIVE WIND LOAD	159.03	90.13	55.14	31.91	20.10	13.46	9.45
	LIVE LOAD/DEFLECTION	197.31	112.18	72.16	50.25	36.98	28.34	22.41
4-span	NEGATIVE WIND LOAD	197.31	84.37	43.20	25.00	15.74	10.55	7.41
	LIVE LOAD/DEFLECTION	184.64	104.86	67.42	46.93	34.53	26.46	20.92


22 Gauge (0.0286"), Fy = 50 ksi, Fu = 60 ksi								
SPAN TYPE	LOAD TYPE	SPAN IN FEET						
1-span	NEGATIVE WIND LOAD	3.0	4.0	5.0	6.0	7.0	8.0	9.0
	LIVE LOAD/DEFLECTION	206.48	116.15	74.33	51.62	37.93	29.04	21.62
2-span	NEGATIVE WIND LOAD	136.17	57.45	29.41	17.02	10.72	7.18	5.04
	LIVE LOAD/DEFLECTION	202.85	114.99	73.86	51.39	37.80	28.96	22.90
3-span	NEGATIVE WIND LOAD	202.85	114.99	70.85	41.00	25.82	17.30	12.15
	LIVE LOAD/DEFLECTION	251.65	143.11	92.06	64.11	47.18	36.16	28.60
4-span	NEGATIVE WIND LOAD	251.65	108.41	55.51	32.12	20.23	13.55	9.52
	LIVE LOAD/DEFLECTION	235.50	133.77	86.01	59.88	44.06	33.77	26.70

*Notes:

1. Strength Calculations based on the 2012 AISI Standard "North American Specification for the Design of Cold-formed Steel Structural Members."
2. Allowable loads are applicable for uniform loading and spans without overhangs.
3. LIVE LOAD/DEFLECTION load capacities are for those loads that push the panel against its support. The applicable limit states are flexure, shear, combined shear and flexure, web crippling at end and interior supports, and a deflection limit of L/180 under strength-level loads.
4. NEGATIVE WIND LOAD capacities are for those loads that pull the panel away from its supports. The applicable limit states are flexure, shear, combined shear and flexure, and a deflection limit of L/60 under 10-year wind loading.
5. Panel pullover and Screw pullout capacity must be checked separately using the screws employed for each particular application when utilizing this load chart.
6. Effective yield strength has been determined in accordance with section A2.3.2 of the 2012 NAS specification.
7. The use of any accessories other than those provided by the manufacturer may damage panels, void all warranties and will void all engineering data.
8. This material is subject to change without notice please contact Flatiron Steel for most current data.

The Engineering data contained herein is for the expressed use of customers and design professionals. Along with this data, it is recommended that the design professional have a copy of the most current version of the **North American Specification for the Design of Cold-Formed Steel Structural Members** published by the American Iron and Steel Institute to facilitate design. The Specification contains the design criteria for cold formed steel components. Along with the Specification, the designer should reference the most current building code applicable to the project jobsite in order to determine environmental loads. If further information or guidance regarding cold-formed design practices is desired, please contact the manufacturer.

Screw Patterns:



Available Gauges: 22 & 24
Weight: 5.00lbs/LnFt (22), 4.00lbs/LnFt (24)
Substrate: AZ-50, Grade D, 50,000ksi
Available Materials: Painted, Galvalume, Core Ten, 16 & 20 oz Copper, Bonderized®
Paint Systems: Durapon70™ PVDF, ULTRA-CLAD™, Kynar500®/Hylar5000®, Valspar™ - Fluropon®
Warranties: Durapon70™ PVDF – 35 year, ULTRA-CLAD™ - 35 year, Zinalume™ AZ50 – 20 year, Valspar™ PVDF - 35 year

Minimum Slope: 1:12 . Under 3:12 requires 1" Butyl sealant and stitch screws installed 1'0" up the panel at side laps

Testing:

- UL 580 Wind Uplift (Class 90)
- UL 2218 Class 4 Hail Impact
- UL 790 Class A Fire Rating



- ASTM E1680
- ASTM E1646
- ASTM E283
- ASTM E330 / E330M
- ASTM E331
- ASTM E1592

APPLICATION DETAILS

Fastener Guide:

#10 Woodfast screws are designed for use with dimensional lumber
 #14 Wafer screws are designed for use with plywood sheathing, OSB, and wafer wood (7/16" minimum thickness)
 #12 Tek Screws are designed to be used with structural steel up to 3/16" thickness

Roof Application: Screws are to be installed following the below details, installed no more than 3'6" up the panel. ****Predrilling is recommended to ensure water tightness**** It is recommended to use 1" Butyl sealant between every panel at the side lap with Stitched Screws installed every 1'0" up the panel. Any slope below a 3:12 must use Bead Seal and Stitch Screws.

Wall Application: Screws are to be installed following the below details, installed no more than 3'6" up the panel. ****Predrilling is recommended to ensure water tightness****

Please Note: It is the responsibility of the builder to ensure that purlins are adequately spaced to meet specific engineering requirements.

****Flatiron Steel is neither partially or solely responsible for improper installation or defects as a result of installation****

11500 21st Street | Greeley, Colorado 80634 | 970.284.6306
 7885 Red Granite Loop | Colorado Springs, Colorado 80939 | 719.591.1114


FLATIRON STEEL

7/8" CORRUGATED

TRIM PROFILES


7/8" Ridge Cap

Item #	Girth	Length	Weight
FS136	12"	10'0"	10.2 lbs.




Overhead Door Trim

Item #	Girth	Length	Weight
FS112	13"	10'0"	10.79 lbs.




7/8" Gable / Rake

Item #	X	Girth	Length	Weight
FS137A	4 3/8" (2x4)	9 3/8"	10'0"	7.78 lbs.
FS137B	6 3/8" (2x6)	11 3/8"	10'0"	9.44 lbs.
FS137C	8 3/8" (2x8)	13 3/8"	10'0"	11.10 lbs.




F+J 1" x 1/2" (Panel to Soffit)

Item #	Girth	Length	Weight
FS128	9 1/4"	10'0"	7.68 lbs.




7/8" Sidewall

Item #	Girth	Length	Weight
FS138	9 1/2"	10'0"	7.89 lbs.



7/8" Prow Gable

Item #	X	Girth	Length	Weight
FS129A	4 5/8" (2x4)	20.25"	10'0"	16.88 lbs.
FS129B	6 5/8" (2x6)	22.25"	10'0"	18.54 lbs.
FS129C	8 5/8" (2x8)	24.25"	10'0"	20.21 lbs.




FLATIRON STEEL

7/8" CORRUGATED

TRIM PROFILES


7/8" Inside Corner

Item #	Girth	Length	Weight
FS139	8½"	10'0"	7.06 lbs.




7/8" Base Trim

Item #	Girth	Length	Weight
FS142	4⅞"	10'0"	3.37 lbs.




7/8" Outside Corner

Item #	Girth	Length	Weight
FS140	8½"	10'0"	7.06 lbs.




7/8" J-Metal

Item #	Girth	Length	Weight
FS143	4½"	10'0"	3.74 lbs.




7/8" Front Cap

Item #	X	Girth	Length	Weight
FS141A	4⅜" (2x4)	11⅜"	10'0"	9.44 lbs.
FS141B	6⅜" (2x6)	13⅜"	10'0"	11.10 lbs.
FS141C	8⅜" (2x8)	15⅜"	10'0"	12.76 lbs.



W-Valley

Item #	Girth	Length	Weight
FS127	20½"	10'0"	17.02 lbs.




FLATIRON STEEL

7/8" CORRUGATED

TRIM PROFILES


Eave (Style A Fascia)

Item #	X	Girth	Length	Weight
FS103A	3½" (2x4)	6"	10'0"	4.98 lbs.
FS103C	5½" (2x6)	8"	10'0"	6.64 lbs.
FS103E	7½" (2x8)	10"	10'0"	8.30 lbs.




Lower Transition

Item #	Girth	Length	Weight
FS109A	12½"	10'0"	10.38 lbs.




Endwall

Item #	Girth	Length	Weight
FS105A	8½"	10'0"	7.06 lbs.




Door Post Trim

Item #	X	Girth	Length	Weight
FS110A	3½" (2x4)	6"	10'0"	4.9 lbs.
FS110C	5½" (2x6)	8"	10'0"	6.7 lbs.
FS110E	7½" (2x8)	10"	10'0"	8.3 lbs.




Upper Transition

Item #	Girth	Length	Weight
FS108A	12½"	10'0"	10.38 lbs.



Style D Eave

Item #	Girth	Length	Weight
FS116A	7½"	10'0"	6.23 lbs.




FLATIRON STEEL

7/8" CORRUGATED

TRIM PROFILES


Snow Stop

Item #	Girth	Length	Weight
FS118A	9 $\frac{9}{16}$ "	10'0"	7.94 lbs.




Z-Flashing

Item #	Girth	Length	Weight
FS119A	3 $\frac{7}{8}$ "	10'0"	3.22 lbs.




L-Angle (Channel)

Item #	Girth	Length	Weight
FS120A		10'0"	




1" Window Drip Cap

Item #	Girth	Length	Weight
FS121B	3 $\frac{3}{8}$ "	10'0"	2.80 lbs.




Square Base Trim

Item #	Girth	Length	Weight
FS122A	4 $\frac{7}{8}$ "	10'0"	4.05 lbs.



Z-Base Trim


Item #	Girth	Length	Weight
FS123A	6 $\frac{1}{4}$ "	10'0"	5.19 lbs.




FLATIRON STEEL

7/8" CORRUGATED

VENTED RIDGE CAP



NON - VENTED RIDGE CAP




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

HIP / RIDGE



FRONT CAP




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

GABLE



EAVE




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

SQUARE BASE



ENDWALL




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

SIDEWALL



SNOW STOP




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

INSIDE CORNER



OUTSIDE CORNER




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

WINDOW DRIP CAP



UPPER TRANSITION




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

LOWER TRANSITION



W- VALLEY




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

Z-BASE



Z-FLASHING




**Details are subject to change without notice.*

FLATIRON STEEL

7/8" CORRUGATED

PROW GABLE




**Details are subject to change without notice.*

FLATIRON STEEL

7/8" CORRUGATED

OVERALL DORMER




**Details are subject to change without notice.*


FLATIRON STEEL

7/8" CORRUGATED

RIDGE TIE-IN



VALLEY TIE-IN



**Details are subject to change without notice.*